Hot Melt Adhesive Troubleshooting Tips



For Package Manufacturers

Cases Popping Open	POSSIBLE CAUSE	TRY
Out of Compression	Hot melt cooling too slowly	Lower application temperature
	Insufficient glue	Check temperature, increase pressure
	Too much adhesive	Check temperature, decrease pressure
	Substrates shift under compression	Adjust compression to maintain uniform
Poor Penetration or Transfer of Adhesive	POSSIBLE CAUSE	TRY
	Temperature too low	Increase temperature
	Not enough adhesive	Increase pressure, temperature, or nozzle size
	Poor mating of substrates	Adjust compression
Stringing	POSSIBLE CAUSE	TRY
	Temperature too low	Increase temperature
	Viscosity too high	Increase temperature
	Nozzle too far from substrate	Adjust nozzle
	Bead placement	Start and stop ¼ inch from edge
	Air movement	Eliminate air drafts
Charring, Gelling, or Smoking of Adhesive in	POSSIBLE CAUSE	TRY
	Temperature too high	Check settings, reduce temperature
	Contamination in reservoir	Cover reservoir and container
Reservoir	Contamination in reservoir Excessive variation of adhesive	Cover reservoir and container Cover reservoir and container
Reservoir	Excessive variation of adhesive	Cover reservoir and container
	Excessive variation of adhesive POSSIBLE CAUSE	Cover reservoir and container TRY
Reservoir	POSSIBLE CAUSE Dirty nozzles	Cover reservoir and container TRY Clean or replace nozzles
Reservoir	Excessive variation of adhesive POSSIBLE CAUSE	Cover reservoir and container TRY
Reservoir	POSSIBLE CAUSE Dirty nozzles Worn orifice or valve Inadequate air pressure	Cover reservoir and container TRY Clean or replace nozzles Check and replace
Reservoir Dripping Nozzle	POSSIBLE CAUSE Dirty nozzles Worn orifice or valve Inadequate air pressure POSSIBLE CAUSE	Cover reservoir and container TRY Clean or replace nozzles Check and replace Increase pressure TRY
Reservoir Dripping Nozzle	POSSIBLE CAUSE Dirty nozzles Worn orifice or valve Inadequate air pressure POSSIBLE CAUSE Moisture in substrate	Cover reservoir and container TRY Clean or replace nozzles Check and replace Increase pressure TRY Dry out substrate
Reservoir Dripping Nozzle	POSSIBLE CAUSE Dirty nozzles Worn orifice or valve Inadequate air pressure POSSIBLE CAUSE	Cover reservoir and container TRY Clean or replace nozzles Check and replace Increase pressure TRY

If you continue to experience problems, contact CGM right away. We're equipped to help you solve "glue-mergencies" of any kind 24/7/365.

I-800-419-GLUE | www.chicagoglue.com | info@chicagoglue.com | 750 Baker Drive, Itasca, IL 60I43