



750 N. BAKER DRIVE, ITASCA, IL 60143 • 1.800.419.4583 • F: 888.371.8314

In this video, we are going to locate and identify the fuses on an Astro D2-15 adhesive supply unit. Be sure to follow all safety precautions stated in the D2-15 manual. The fuses are located in the electrical housing. To access them, we will use a 3/32 Allen wrench to remove the screw that secures the front door. Be sure to lock and tag out power to the melter before handling the fuses. To remove the fuse holder, turn to the left and pull out. Insert and turn to the right to secure it back in place. The fuse holders will be labeled. F1 and F2 are for the tank heaters. F1 for heater 1 and F2 for heater 2. These are 8-amp fuses. Their replacement part number is 12014-8B. F3 is the motor fuse. This is a 5-amp fuse. Its replacement part number is 12014-5B. The last two fuses, F4 and F5, are for the hoses and the guns. Both of these are 6.3 amp fuses. F4 is for hose and gun 2 and F5 is for hose and gun 1. The replacement part number for both F4 and F5 is 939683.